
Operating System Messaging

OSM messages

OSM0000	Example message for {string}.
OSM0001	Cannot create pipe, errno x.
OSM0002	Cannot open pipe for read/write, errno x.
OSM0003	Cannot create OSM File semaphore, errno x.
OSM0004	Cannot open OSM file for appending, errno x.
OSM0005	Cannot open save file for writing, errno x.
OSM0006	Cannot get OSM Save file semaphore errno x.
OSM0007	Cannot save OSM file (copy failed), errno x.
OSM0008	Cannot get OSM write file semaphore, errno x.
OSM0009	Cannot fprintf to osm File, errno x.
OSM0010	Cannot read from pipe, errno x.
OSM0011	OsmTask has died.
OSM0012	Cannot spawn osm Task, errno x.
OSM0013	Cannot spawn period task, errno x.
OSM0014	Daily log file save failed. Check CMDU power on/off switch. Action: Be sure the IOP enable/disable switch is enabled (up).

OSM0015	Disk getting full. Only x bytes remain. Action: Contact your technical service representative.
OSM0016	X byte log file size limit exceeded. Disk getting full, only y bytes remain. Action: Contact technical support.
OSM0017	Cannot flush to log file errno {x}.